






Note: Always swab port with sterile alcohol prior to accessing with a sterile syringe.

<p>Step 1:</p>  <p>Using the sterile filtered needle, Draw 2mL of Citrate Anticoagulant into 20mL Syringe</p>	<p>Step 2:</p>  <p>Draw 18mL whole blood from the patient, filling the syringe to 20mL. Gently, but thoroughly mix the blood and anticoagulant upon collection to prevent coagulation.</p>	<p>Step 3:</p>  <p>Unscrew the device cap and slowly add the 20mL of anticoagulated whole blood into the Concentrating Device. Screw the device cap onto the device and load into the Executive Series Centrifuge II machine.</p>
<p>Step 4:</p> <p>Counterbalance the Concentrating Device according to the IFU insert and centrifuge at:</p> <p>Executive Series Centrifuge</p> <p>1 minute 4000 RPM</p>	<p>Step 5:</p>  <p>After centrifugation, the platelets will remain suspended in the plasma solution, forming the high yielding PRP.</p>	<p>Step 6:</p>  <p>Using the 12mL syringe, aspirate the high yielding PRP, leaving the RBCs behind.</p>